




Lock-n-Haul Advanced Outboard Transom Saver Model LnHG2-2
Install on Evinrude G2 Outboard

<p>1.</p> <p>Start by centering motor. Raise motor high enough to allow the flat ends to be inserted into the bottom set of recesses so the the Delrin bar will clear the tray.</p>	
	<p>2.</p> <p>Maintain contact with the lower motor mount flange bolts by pushing back toward the prop and uptoward the top of the motor.</p>
<p>3.</p> <p>Hold the device in place and lower motor until the tilt motor changes sound indicating fully loaded.</p>	
<p>Scan this QR code to see the video on the installation of the device.</p>	